



## TECHNICAL DATA SHEET

### PRODUCT DESCRIPTION

Two-Pack epoxy undercoat for use above and below waterline. Suitable undercoat prior to the application of Polygloss finish and all OceanMaster antifouling products.

### PRODUCT INFORMATION

**Finish** : Matt White / Matt Grey

### DIRECTIONS FOR USE

#### Usage

Boat hulls after fairing, steel and aluminium after priming, or directly on fibreglass and timber. All marine situations prior to top coating or antifouling.

#### Coverage

09 sqm/litre – depending on usage & substrate

#### Mixing Ratio

3:1 by volume.

#### Recoating time

4 hours max or once tack free

Sand surface if time exceeds or when preparing for overcoating with a paint system.

#### Thinner

T500

#### Curing Time

24 hours

#### Pack Sizes

1 Litre / 4 litres.

### QUICK TIPS

Product designed for spray/brush application

Key to ensuring a good job is to ensure proper surface preparation on various substrates before coating.

Use T500 thinner if necessary to degrease or wipe down surface prior to product application

Apply min 2 coats of Everguard undercoat before rolling on the topcoat. This is important for fibreglass / wooden decks where moisture might hinder proper adhesion of material. For metal surfaces, ensure 2 coats of Universal anticorrosive primer before undercoat.

### RECOMMENDED SPRAY GUN SETUP : BINKS

FLUID NOZZLE: 65-SS 45-6501 (1.5MM)

FLUID NEEDLE: 565 47-56500

AIR NOZZLE 63-PR 46-6079

Wet Film Thickness: 100 Microns

Dry Film Thickness: 50 Microns

**CONTACT US  
TODAY  
FOR PAINT ESTIMATES  
AND TECHNICAL ADVICE**



#### OMI Coatings

102F Pasir Panjang Road #01-01  
Citilink Warehouse Complex  
Singapore 118530



T. +65 6777 6001  
F. +65 6777 9006



omicoat.com  
info@omicoat.com